

COMPATIBLE WITH THE FOLLOWING AND MORE:

Electric Scooters

- GT Scooter Tsunami (Requires 2 Batteries)
- Mongoose Fusion (Requires 2 Batteries)
- Rad2Go Q Chariot Segway (Requires 2 Batteries)
- Rad2Go Tiger Shark E10 (Requires 2 Batteries)
- Schwinn X-CEL (Requires 2 Batteries)
- X-Treme X-50-500 (Requires 2 Batteries)
- X-Treme XA-1000 ATV5
- X-Treme XA-750 v2 (Requires 3 Batteries)
- X-Treme XB-420M (Requires 4 Batteries)
- X-Treme XB-600 (Requires 4 Batteries)
- Xcooter Blaster XC300GT (Requires 2 Batteries)
- Xcooter Xcaddy
- X-Treme XA-75

UPS Batteries

- Alpha Technologies 1500 (Requires 4 Batteries)
- Alpha Technologies 2200 (Requires 4 Batteries)
- Alpha Technologies 600 (Requires 2 Batteries)
- Alpha Technologies AS1000 (Requires 3 Batteries)
- Alpha Technologies AS1500 (Requires 4 Batteries)
- Alpha Technologies AS2000 (Requires 4 Batteries)
- APC AP1250 (Requires 2 Batteries)
- APC AP1250RM (Requires 2 Batteries)
- APC AP1400 (Requires 4 Batteries)
- APC AP200RM (Requires 4 Batteries)
- APC AP200XL (Requires 4 Batteries)
- APC AP280 (Requires 4 Batteries)
- APC AP900XL (Requires 4 Batteries)
- APC BACK-UPS 1250 (Requires 2 Batteries)
- APC BACK-UPS 200 (Requires 2 Batteries)

Mobility Scooters

- ActiveCare Spitfire EX 1420
- Amigo RT Pack (Requires 2 Batteries)
- BladeZ Electric Travelmate (Requires 2 Batteries)
- Bruno Cub 35 FWD - U1 optional (Requires 2 Batteries)
- Bruno Cub Pediatric 18 AH (Requires 2 Batteries)
- Bruno Typhoon C3 (Requires 2 Batteries)
- Damaco Child's Elite - 14x14 (Requires 2 Batteries)
- DDC Shoprider 777E (Requires 2 Batteries)
- DDC Shoprider Snazzy (Requires 2 Batteries)
- DDC Shoprider Sunrunner (Requires 2 Batteries)
- Frank Mobility E-Fix - E19 Model (Requires 2 Batteries)
- Invacare Lynx SX-3
- Invacare Lynx SX-3p
- Levo LC (Requires 2 Batteries)
- Medline Industries Gemini 1 (Requires 2 Batteries)
- Merits Merits P120, P1201, P12011, P12012 Travel-Ease Regal (Requires 2 Batteries)
- Merits Merits P320, P3201, P32011, P32012 Junior (Requires 2 Batteries)
- Merits Merits S235, S2351, S2353, S2354 Pioneer 1 (Requires 2 Batteries)
- Merits Merits S245, S2451, S2454 Pioneer 2 (Requires 2 Batteries)
- Merits Merits S246 Pioneer 2 Twin (Requires 2 Batteries)
- Pride Mobility Rally (Requires 2 Batteries)
- Rascal 200T (Requires 2 Batteries)
- Rascal 320 PC (Requires 2 Batteries)
- Rascal 500T (Requires 2 Batteries)
- Rascal Rascal 110 (Requires 2 Batteries)
- Rascal Rascal 120 (Requires 2 Batteries)
- Shoprider Cutie L (Requires 2 Batteries)
- Shoprider Dasher 9 (Requires 2 Batteries)
- Shoprider Start 8 (Requires 2 Batteries)
- Suiter Destination (Requires 2 Batteries)
- Wheelcare Caddy (Requires 2 Batteries)
- Wheelcare Superlight (Requires 2 Batteries)

- APC BACK-UPS BK1200 (Requires 2 Batteries)
- APC BACK-UPS BK1250 (Requires 2 Batteries)
- APC BACK-UPS PRO BP1400 (Requires 2 Batteries)
- APC BACK-UPS PRO BP1400X116 (Requires 2 Batteries)
- APC BACK-UPS VS SUVVS1400 (Requires 2 Batteries)
- APC RBC7
- APC SMART-UPS 24XLBP (Requires 4 Batteries)
- APC SMART-UPS DLA1500 (Requires 2 Batteries)
- APC SMART-UPS RM SU1400RMXLNET (Requires 4 Batteries)
- APC SMART-UPS RM SU1400RMXLNET (Requires 4 Batteries)
- APC SMART-UPS RM SU2200RM (Requires 4 Batteries)
- APC SMART-UPS RM SU2200RMNET (Requires 4 Batteries)
- APC SMART-UPS RM SU2200RMXL (Requires 4 Batteries)
- APC SMART-UPS RM SU2200RMXLNET (Requires 4 Batteries)
- APC SMART-UPS RM SU2200RMXLNET (Requires 4 Batteries)
- APC SMART-UPS RM SU2200RMXLTX153 (Requires 4 Batteries)
- APC SMART-UPS RM SU2200X179 (Requires 4 Batteries)
- APC SMART-UPS RM SU3000
- APC SMART-UPS RM SU3000NET (Requires 4 Batteries)
- APC SMART-UPS RM SU3000R3BX120 (Requires 4 Batteries)
- APC SMART-UPS RM SU3000RM (Requires 4 Batteries)
- APC SMART-UPS RM SU3000RMNET (Requires 4 Batteries)
- APC SMART-UPS RM SU3000RMX93 (Requires 4 Batteries)
- APC SMART-UPS RM SU3000US (Requires 4 Batteries)
- APC SMART-UPS RM SUA15002X93 (Requires 4 Batteries)
- APC SMART-UPS RM SUA1500X93 (Requires 2 Batteries)
- APC SMART-UPS SU1000XL (Requires 2 Batteries)
- APC SMART-UPS SU1000XL NET (Requires 2 Batteries)
- APC SMART-UPS SU1250 (Requires 2 Batteries)
- APC SMART-UPS SU1250 RACK (Requires 2 Batteries)
- APC SMART-UPS SU1400 (Requires 2 Batteries)
- APC SMART-UPS SU1400BX120 (Requires 2 Batteries)
- APC SMART-UPS SU1400NET (Requires 2 Batteries)
- APC SMART-UPS SU1400X106 (Requires 2 Batteries)
- APC SMART-UPS SU1400X145 (Requires 2 Batteries)
- APC SMART-UPS SU1400X93 (Requires 2 Batteries)
- APC SMART-UPS SU1400XLNET (Requires 4 Batteries)

Alarm Batteries

- ADT Security Alarm 476746
- ADT Security Alarm 4520615

- APC SMART-UPS SU2000 (Requires 4 Batteries)
- APC SMART-UPS SU2000XL (Requires 4 Batteries)
- APC SMART-UPS SU2200 (Requires 4 Batteries)
- APC SMART-UPS SU2200BX120 (Requires 4 Batteries)
- APC SMART-UPS SU2200NET (Requires 4 Batteries)
- APC SMART-UPS SU2200US (Requires 4 Batteries)
- APC SMART-UPS SU2200X106 (Requires 4 Batteries)
- APC SMART-UPS SU2200X111 (Requires 4 Batteries)
- APC SMART-UPS SU2200X115 (Requires 4 Batteries)
- APC SMART-UPS SU2200X180 (Requires 4 Batteries)
- APC SMART-UPS SU2200X93 (Requires 4 Batteries)
- APC SMART-UPS SU2200XL (Requires 4 Batteries)
- APC SMART-UPS SU2200XLNET (Requires 4 Batteries)
- APC SMART-UPS SU2200XLNET (Requires 4 Batteries)
- APC SMART-UPS SU2200XLTX153 (Requires 4 Batteries)
- APC SMART-UPS SU3000 (Requires 4 Batteries)
- APC SMART-UPS SU3000NET (Requires 4 Batteries)
- APC SMART-UPS SU3000TNET (Requires 4 Batteries)
- APC SMART-UPS SU3000US (Requires 4 Batteries)
- APC SMART-UPS SU3000X177 (Requires 4 Batteries)
- APC SMART-UPS SU48XLBP (Requires 4 Batteries)
- APC SMART-UPS SU600XL (Requires 4 Batteries)
- APC SMART-UPS SU700XL (Requires 2 Batteries)
- APC SMART-UPS SU700XLNET (Requires 2 Batteries)
- APC SMART-UPS SUA1000XL (Requires 2 Batteries)
- APC SMART-UPS SUA1500 (Requires 2 Batteries)
- APC SMART-UPS SUA1500US (Requires 2 Batteries)
- APC SMART-UPS SUA2200 (Requires 4 Batteries)
- APC SMART-UPS SUA3000 (Requires 4 Batteries)
- APC SMART-UPS SUA5000R5TXFMR (Requires 8 Batteries)
- APC SMART-UPS SUA5000RMT5U (Requires 8 Batteries)
- APC SMART-UPS SUA750XL (Requires 2 Batteries)
- APC SMART-UPS SUVS1400 (Requires 2 Batteries)
- APC SMART-UPS XL SUA1000XL (Requires 2 Batteries)
- APC SMART-UPS XL SUA2200XL (Requires 4 Batteries)
- APC SMART-UPS XL SUA2200XL-NETPKG (Requires 4 Batteries)
- APC SMART-UPS XL SUA3000XL (Requires 4 Batteries)
- APC SMART-UPS XL SUA3000XL-NETPKG (Requires 4 Batteries)

- APC SMART-UPS XL SUA3000XLT (Requires 4 Batteries)
- APC SMART-UPS XL SUA750XL (Requires 2 Batteries)
- Belkin BERBC60 (Requires 2 Batteries)
- Belkin Pro F6C100-4 (Requires 2 Batteries)
- Belkin Pro NETUPS F6C100-4 (Requires 2 Batteries)
- Best Technologies Micro-FERRUPS FE1.4KVA
- Clary Corporation 3758532
- Clary Corporation CLA7026
- Clary Corporation UPS11K1GSBS
- Clary Corporation UPS125K1GSBS
- Clary Corporation UPS125K1GSBSR
- Clary Corporation UPS12K1GSBS
- Clary Corporation UPS12K1GSBSR
- Clary Corporation UPS1375K1GSBS
- Clary Corporation UPS1375K1GSBSR
- Clary Corporation UPS13K1GSBS
- Clary Corporation UPS13K1GSBSR
- Clary Corporation UPS2375K1GSBS
- Clary Corporation UPS2375K1GSBSR
- Clary Corporation UPS23K1GSBS
- Clary Corporation UPS23K1GSBSR
- Compaq T1500 (Requires 2 Batteries)
- Cyber Power CS20A-EBP
- Cyber Power CS30U12V-20
- Cyber Power CS50U48V
- Cyber Power CS75A12V3
- Cyber Power OP1500 (Requires 2 Batteries)
- Data Shield 800 (Requires 2 Batteries)
- Data Shield AT800 (Requires 2 Batteries)
- Data Shield TURBO 2-625
- Dell DL1500 (Requires 2 Batteries)
- Deltec PRA 1500 (Requires 2 Batteries)
- Deltec PRA 2000 (Requires 4 Batteries)
- Deltec PRA1000A (Requires 2 Batteries)
- DynaTech SPF-550-2 (Requires 2 Batteries)
- DynaTech SPF-560-2 (Requires 2 Batteries)
- Elgar IPS1100 (Requires 4 Batteries)
- Elgar IPS550 (Requires 2 Batteries)

- Elgar SPF1000 (Requires 4 Batteries)
- Elgar SPF1100 (Requires 4 Batteries)
- Elgar SPF550-2 (Requires 2 Batteries)
- NCR 4070-1500-7194 (Requires 2 Batteries)
- Para System MINUTEMAN 1600 (Requires 4 Batteries)
- Para System MINUTEMAN BP192V17 (Requires 16 Batteries)
- Para System MINUTEMAN BP24V34 (Requires 4 Batteries)
- Para System MINUTEMAN BP48V17A (Requires 4 Batteries)
- Para System MINUTEMAN BP48V34 (Requires 8 Batteries)
- Para System MINUTEMAN BP60V17 (Requires 5 Batteries)
- Para System MINUTEMAN BPX48V17 (Requires 4 Batteries)
- Para System MINUTEMAN CP 10K2 (Requires 16 Batteries)
- Para System MINUTEMAN MSU 1400 (Requires 2 Batteries)
- Para System MINUTEMAN MSU 1400i (Requires 2 Batteries)
- Para System MINUTEMAN PML 2000 (Requires 4 Batteries)
- Para System MINUTEMAN PML 20002 (Requires 4 Batteries)
- Para System MINUTEMAN PRO 1400 (Requires 2 Batteries)
- Para System MINUTEMAN PRO 1400i Version 1 (Requires 2 Batteries)
- Para System MINUTEMAN Pro BPr1 (Requires 4 Batteries)
- Para System MINUTEMAN PX 101.4 (Requires 2 Batteries)
- Para System MINUTEMAN S 1400 (Requires 2 Batteries)
- Para System MINUTEMAN S 2000 (Requires 2 Batteries)
- Para System MINUTEMAN XRT BP1 (Requires 4 Batteries)